



Packable Wind Jacket EB500



Wind was the inspiration for this compact layer—and it packs down into a pocket, making it easy to carry wherever you go. Hood with drawcord and toggles for adjustability, contrast reverse coil zipper, underarm vents, packable zippered chest pocket, front unzipped pockets, elastic cuffs and an open hem. Contrast Eddie Bauer logo on right chest. Made of 100% nylon.

CARE INSTRUCTIONS

Secure all garment before laundering Machine wash warm delicate separately Use mild detergent rinse thoroughly Do not bleach Tumble dry low or for best result line dry Do not iron. Do not dry clean




front



back

HOW TO MEASURE



CHEST

With arms down at sides, measure around the upper body, under arms and over the fullest part of the chest.

SIZE CHART

	XS	S	M	L	XL	2XL	3XL	4XL
Chest	32-34	35-37	38-40	41-43	44-46	48-50	52-54	55-57

COLOR INFORMATION

